



TR3 OVERVIEW

- **TR3 L-Form with ENG-lens-control for Zoom and Focus**
- **TR3 L-Form with Film-lens-control for Zoom, Focus and Iris**
- **TR3 R-Form with Film-lens-control for Zoom and Focus**
- **TR3 R-Form with ENG-lens-control for Zoom and Focus**



- **Items TR3 L-Form Video and Film with options**
- **Items TR3 R-Form Video and Film with options**

- **Items Film- and ENG-lens-control**


TR3 L-Form with ENG-lens-control



TR3 L-Form with Film-lens-control



TR3 R-Form with Film-lens-control



Control-Electronics



Flat-base Halfball Mitchell

Control-Head



Crankwheel
Add-on



Uni plug-in

Joystick
Alternative




Power Supply




Flight case



TR3 R-Form with ENG-lens-control



Control-Electronics




Control-Head



Crankwheel Add-on



Joystick Alternative



Power Supply

Flight case



TR3 L-Form basic-version and options

Remote-Head TR3	1	TR30-E-000	Remote-Head with slip-rings	
Basic-version	1	TR30-E-280	Triax-socket "Fischer"	
	1	TR30-E-011	Control-head TR3-8 without control-electronics	
	1	TR30-E-071	Control-electronics TR3-8	
	1	TR30-E-210	Remote-cable 20m	
	1	TR30-E-240	Power-cable 20m	
	1	TZ00-E-030	Power-supply 115/230V/14V/16A	
	1	TZ00-E-060	Uni plug-in power	
	1	TR30-E-003	Mitchell-Adapter	
	1	TR30-E-090	Camera-carrying support with worm-spindle	
options:	1	TR30-E-270	Case 3-parts	
	1	TR30-E-002	Halfball for Remote-Head	repl. TR30-D-003
	1	TR30-E-310	Flat-base for Pedestal	repl. TR30-D-003
	1	TR30-E-220	Remote-cable 40m	
	1	TR30-E-021	Joystick without control-electronics	repl. TR30-D-011
Add to TR30-E-011	2	TR30-E-030	Crankwheel-unit for Pan/Tilt (2 helix-cable)	
Add to -030	2	TR30-E-060	Helix-cable, 3m	
	1	TR30-E-091	Camera-carrying support without worm-spindle	repl. TR30-D-090
	1	TR30-E-260	Crane-distribution (1 remote-cable)	
	1	TR30-E-210	Remote-cable 20m	
	1	TR30-E-250	Redlight-sensor for Remote-Head	
Film-lens-drive	1	TR30-E-145	Camera-plate without lens-support	
Film-lens-drive	1	TR30-E-146	Lens-support for camera-plate (15mm)	
Film-lens-drive	1	TR30-E-147	Lens-support for camera-plate (20mm)	

TR3 R-Form Basic-version and options

Remote-Head TR3 Roll	1	TR30-E-000	Remote-Head with slip-rings	
Basic-Version	1	TR30-E-280	Triax-socket "Fischer"	
	1	TR30-E-011	Control-head TR3-8 without control-electronics	
	1	TR30-E-071	Control-electronics TR3-8	
	1	TR30-E-210	Remote-cable 20m	
	1	TR30-E-240	Power-cable 20m	
	1	TZ00-E-030	Power-supply 115/230V/14V/16A	
	1	TR30-E-003	Mitchell-Adapter	
	1	TR30-E-005	Roll-axis max. +/-360°	
	1	TR30-E-008	Cable support for roll-axis	
	1	TR30-E-040	Manual regulator for zoom	
	1	TR30-E-060	Helix-cable, 3m	
	1	TR30-E-130	Connection-cable for lens-drive, short	
options:	1	TZ00-E-060	Uni-plug-in power	
	1	TR30-E-270	Case 3-parts	
	1	TR30-E-002	Halfball for Remote-Head	repl. TR30-D-003
	1	TR30-E-310	Flat-base for Pedestal	repl. TR30-D-003
	1	TR30-E-220	Remote-cable 40m	
	1	TR30-E-021	Joystick without control-electronics	repl. TR30-D-011
Add to TR30-E-011	2	TR30-E-030	Crankwheel-unit for Pan/Tilt (2 helix-cable)	
Add to -030	2	TR30-E-060	Helix-cable, 3m	
	1	TR30-E-260	Crane-distribution (1 remote-cable)	
	1	TR30-E-210	Remote-cable 20m	
	1	TR30-E-250	Redlight-sensor for Remote-Head	
Film-lens-drive	1	TR30-E-145	Camera-plate without lens-support	
Film-lens-drive	1	TR30-E-146	Lens-support for camera-plate (15mm)	
Film-lens-drive	1	TR30-E-147	Lens-support for camera-plate (20mm)	

ENG-lens-control for Zoom/Focus Film-lens-control for Zoom, Focus and Iris

Control Zoom/Focus	1	TR30-E-040	Manual regulator for Zoom	
ENG-Lens	1	TR30-E-050	Manual regulator for Iris or Focus	
	2	TR30-E-060	Helix-cable 6-pol, 3m	
	1	TR30-E-100	Servo-elektronics for 3 lens-drives	
	1	TR30-E-110	Cable Control-E. to Remote-Head	
	1	TR30-E-151	Lens-drive with bolt	
	1	TR30-E-160	Attachment ENG/CANON/Fujinon	
	1	TR30-E-200	Cable für Fujinon-lens	
	1	TR30-E-150	Lens-drive ENG without bolt	
Control Zoom/Focus/Iris	1	TR30-E-040	Manual regulator for Zoom	
Film-Lens	2	TR30-E-050	Manual regulator for Iris and Focus	for roll-axis 1 pc.
	3	TR30-E-060	Helix-cable 6-pol, 3m	
	1	TR30-E-100	Servo-elektronics for 3 lens-drives	
	3	TR30-E-120	TR3 lens-drive for Film-lens	
	3	TR30-D-130	Connector cable for Film-lens-motor, short	for roll-axis 2 pc.
		or		
	3	TR30-D-131	Connector cable for Film-lens-motor, long	for roll-axis 2 pc.
	1	TR30-E-110	Cable Control-E. to Remote-Head	
	2	TR30-E-140	Attachment frame short for lens-drive	
	2	TR30-E-141	Attachment frame long for lens-drive	
	2	TR30-E-907	Spacer sleeve d15/19	
	1	TR30-E-908	Spacer sleeve d20/32	
	1	TR30-E-909	Spacer sleeve 19/32	
	1	TR30-D-170	ARRI 3-pol Remote-cable	
	1	TR30-E-180	ARRI 11-pol Remote-cable	
	1	TR30-E-190	Moviecama Remote-cable for Aaton	
	1	TR30-E-205	Remote-cable for Aaton 35II + XTR16	